# FCP661 & FCP663, PENDANTS — INSTALLATION INSTRUCTIONS

CAUTION: BEFORE CONNECTING THE LUMINAIRE TO A POWER SUPPLY, MAKE SURE THE POWER IS SWITCHED OFF.

# FCP661 FCP663



www.fclighting.com 3609 Swenson Ave. St. Charles, IL 60174

## **DETAILED ILLUSTRATION**

### GENERAL:

- 1. Luminaires must be installed by licensed electrician.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code.
- Before starting the installation, make sure all electricity has been turned off and electrical breaker has been locked out and tagged out.
- To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before beginning.

**NOTE:** The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur.

## **INSTALLATION INSTRUCTIONS:**

- Remove both Set Screws located at the top of the Canopy. Set aside for later.
- 2. Carefully slide Canopy cover down Aircraft Cables and Power Cord.
- Using the access slots in the mounting plate, attach the unit to the Junction Box.
  - a. If necessary, additional mounting locations can be uncovered by removing the 4 nuts located along the perimeter of the mounting plate.
- 4. Connect the White, Black and Green wires to input power from Junction Box. Dimming leads will also need to be connected to controls. If height adjustment of the Aircraft Cables are needed, cut to desired length above the cable grip. DO NOT REMOVE AIRCRAFT CABLES FROM CABLE GRIPS.
- Slide Canopy back into original position, re-fasten both Set Screws back into place.

